


ECO WO MULTI OIL BURNERS INSTALLATION, OPERATING AND MAINTENANCE INSTRUCTIONS



ECO WO-20
ECO WO-55
ECO WO-75
ECO WO-100
ECO WO-150
ECO WO-200

17.10.2018 Rev. 01

DEAR USER,

ECO WO-20, ECO WO-55, ECO WO-75, ECO WO-100, ECO WO-150, ECO WO-200, multi oil burners are prepared and manufactured in line with the latest technical inventions and safety rules. It is easy to use for our customers.

We recommend that you read this manual and safety warnings thoroughly before the use of the device in order to ensure safe, cost effective and environmental-friendly use.

If you encounter any issue that is not explained clearly in this manual or you could not understand, please contact with our service department.

We thank you for choosing **ECOSTAR** brand.







This Operating Manual is an integral part of the burner and must be maintained in a plastic dossier and hung at a clearly visible place in the burner room.

CONTENTS

1.	WARNINGS	3
1.1.	Warning Symbols and Descriptions	3
1.1.	General Safety Rules	4
	BURNER ROOM	5
2.	TERMS OF WARRANTY	6
2.1.	Out of Warranty Conditions	6
3.	BURNER'S GENERAL FEATURES	7
4.	TECHNICAL DATA	8
4.1.	Capacity and Technical Chart.....	8
4.2.	Capacity Diagrams	9
4.3.	Oil Consumption – Primary Air Pressure	11
4.4.	Burner Components.....	12
4.5.	Outer Dimensions.....	17
4.6.	Noise Level	17
4.7.	Basic Settings	18
4.8.	Function Description	18
5.	REGULATIONS	20
5.1.	Primary air regulator.....	20
5.2.	Secondary air regulator.....	20
6.	ATTENTION PLEASE - A SUMMARY OF IMPORTANT POINTS REGARDING “ECO WO” .	21
7.	INSTALLATION & COMMISSIONING.....	22
7.1.	Setting Into Operation	22
7.2.	Flame Ring And Ignition Electrode.....	23
8.	TROUBLESHOOTING	24
9.	ELECTRICAL DIAGRAM.....	25
10.	PERIODICAL FLUE GAS MEASUREMENT REPORT	26
11.	AFTER SALES SERVICES	27
12.	NOTES	28

1. WARNINGS

1.1. Warning Symbols and Descriptions

Symbols	Symbol Descriptions
	Important information and useful hints.
	Warning of danger to life or property.
	Warning of electrical voltage.
	Product handling information.
	Electric motor direction of rotation
	Carry in an upright position. Fragile Item. Protect against water.

1.1. General Safety Rules

- All personnel engaged in installation, disassembly, commissioning, operation, control, maintenance and repair should have received the necessary training and fully read and understood this manual.
- No changes that might damage the safety of the burner unit must be made by persons and/or organizations on the burner unit.
- All operation, commissioning and installation works (except for burning adjustment) should be carried out when the burner is not operating and after disconnecting the power supply. Noncompliance with these rules may lead to serious bodily injuries and even death by electrical shocks or uncontrolled flame formation.
- Repairs concerned with safety elements should be carried out only by the manufacturing company.
- The device should never be used by children, mentally handicapped and inexperienced persons.
- Children must not be allowed to play with the device.
- Keep the device away from explosive and flammable materials.
- Device must intake air, ventilation and air discharge holes must not be closed.



Do not store any inflammable materials in boiler room.



Wear hearing protectors if there is noise in boiler room.



In case of fire or other emergency;

- Switch off the main switch
- Take appropriate actions



The burner installation must be carried out in accordance with the instructions. Vibration can damage the burner and its components.



Keep boiler doors closed while starting burner and during burner operation.



Check combustion values to be correct by using flue gas analyzer at the whole adjustment range between minimum, full load, and ignition load.



Use lifting device or belt for lifting fan motor, if necessary.



During the first commissioning of the burner or in case of any revision carried out in the electrical system or motor cables by any reason, direction of the fan rotation must certainly be checked by the authorized technical service.



For products that have not been commissioned or started more than 6 months, before activating the servomotor;

In air dampers and oil regulators, servomotor and air damper connections must be checked to ensure that they are free running in spite of immobility and oil freezing.



BURNER ROOM

Install the burner in a suitable room/floor with minimum external air openings and sufficient to ensure perfect combustion, in compliance with current regulations.

Never obstruct air openings of the burner room, burner fan intake vents or air ducts in order to prevent:

- a. The build up of toxic / explosive gas mixtures in the burner room,
- b. Combustion with insufficient air, resulting in hazardous, anti-economical and polluting operation.

The burner must be always protected from rain, snow and frost to prevent corrosion and paint deformations.

Keep the burner room clean and free of solid volatile substances, which could be sucked into the fan and clog the internal burner or combustion head air ducts.

2. TERMS OF WARRANTY

Main and auxiliary equipment and all components used in Ecostar light oil burners are guaranteed for 1 year by TERMO ISI SİST. A.Ş starting from the date of commissioning under the maintenance, adjustment, operating conditions and relevant mechanic, chemical and thermal effects explained herein.



Please note that this warranty is only valid if the device(s) is commissioned and maintained by our authorized services.



Our company reserves the right to make any modifications on the product and all instructions thereof for improvement purposes.

2.1. Out of Warranty Conditions

- Any damage arising out of or in relation to customers' non-compliance to their responsibilities with regards to installation, commissioning, operation and maintenance,
- Any damage arising out of or in relation to commissioning, repairs and maintenance carried out by unauthorized services,
- Any damage that may occur during transportation or storage of the product,
- Not preserving the product in its original packaging until the installation stage,
- Incorrect and poor electrical connections, Failures due to incorrect voltage applications, frequent repetition of voltage fluctuations,
- Any damage that may occur as a result of incorrect fuel usage or, foreign substances in the fuel used or using of the product without any fuel,
- Any damage that may occur due to foreign particles entered into the product during installation and operation,
- Failures due to incorrect device selection,
- Any damage to unit due to natural disasters,
- Devices without any warranty certificates,
- Warranty Certificates without the stamp and signature of the authorized dealer or service,
- Devices with any falsification on the warranty certificate or without an original serial number.
- The risks during transportation of device under the responsibility of customer belong to the customer.
- Presence of misuse faults are indicated in the reports issued by authorized service stations or our authorized agent, dealer, representative or our factory in case of unavailability of authorized service stations.
- Customers may apply consumer protection arbitrator committee with regards to this report and request for an expert report.

3. BURNER'S GENERAL FEATURES

ECOSTAR multi oil burners are used in motor workshops, garages, etc. to burn black oil, diesel, waste oil as well as plant oil and similar fuel types.

The burners are designed to be used for; closed hot water central heating systems, central hot water generation, industrial process heat, warm air generators.

ECOSTAR multi oil burner use fuels as: domestic oil, vegetable oil, waste oil or mixtures without alteration of burner, primary regulation, only adjustment per air regulator and oil temperature regulator.

Each part is easily accessible, which provides easy maintenance and cleaning. All burners are equipped with electronic control equipment (thermostats, manometers, valves, etc.) to reliably control fuel burning.



Collect and store your oil continuously according valid regulations.



When using waste oil, water and sludge are not combustible!



This device must never not be operated with open flame!

4. TECHNICAL DATA


4.1. Capacity and Technical Chart

BURNER TYPE	OIL CONSUMPTION		BURNER CAPACITY		FAN MOTOR POWER	VOLTAGE AT 50 Hz	OIL HEATER	WEIGHT
	Min. Kg/h	Max. Kg/h	Min. kW	Max. kW	kW	V	kW	Kg


ECO WO-20	2,5	3,9	26	38	0,11	220-380	1	20
ECO WO-55	3,6	5,2	37	54	0,11	220-380	1	20
ECO WO-75	5,4	7,8	56	81	0,15	220-380	1	26
ECO WO-100	7,8	9,6	81	100	0,15	220-380	1	26
ECO WO-150	8,9	14,1	93	147	0,15	220-380	1	26
ECO WO-200	12,7	18	131	187	0,15	220-380	1	26

4.2. Capacity Diagrams


ECO WO-20




ECO WO-55




ECO WO-70




ECO WO-100




ECO WO-150



ECO WO-200




4.3. Oil Consumption – Primary Air Pressure




ECO WO-20/55			
No	Name	No	Name
1	Burner Body	23	Nozzle
2	Flame Tube Connection Flange	24	Control Box-1
3	Seal Flange-1	25	Relay
4	Flame Tube	26	Control Box Cover-1
5	Burner Flange	27	Burner Control Relay
6	Seal Flange-2	28	Transformer
7	Fan	29	Control Box-2
8	Fan Motor	30	Limit Switch
9	Fuel Pump	31	Temperature Regulator
10	Shaft	32	Overheat Thermostat
11	Shaft Centering Plate	33	Control Box Cover-2
12	Sight Glass	34	Fuel Suction Pipe
13	Air Klappe	35	Float
14	Air Scale	36	Heating Element
15	Purger	37	Sensor Holder
16	Fuel Solenoid Valve	38	Fuel Tank
17	Air Regulator	39	Overflow Switch
18	Air Solenoid Valve	40	Overflow Tank
19	Air Distributor and Manometer	41	Photocell
20	Nozzle Adaptor	42	Tank Cover
21	Flame Ring	43	Air Safety Valve
22	Ignition Electrode		

ECO WO-70/100




ECO WO-150/200




ECO WO-70/100/150/200			
No	Name	No	Name
1	Burner Body	24	Ignition Electrode
2	Seal Flange-1	25	Nozzle
3	Flame Tube Connection Flange	26	Control Box-1
4	Seal Flange-2	27	Relay
5	Flame Tube	28	Control Box Cover-1
6	Burner Flange	29	Burner Control Relay
7	Seal Flange-2	30	Transformer
8	Fan	31	Control Box-2
9	Fan Motor	32	Limit Switch
10	Fuel Pump	33	Temperature Regulator
11	Shaft	34	Overheat Thermostat
12	Shaft Centering Plate	35	Control Box Cover-2
13	Sight Glass	36	Fuel Suction Pipe
14	Air Klappe	37	Float
15	Air Scale	38	Heating Element
16	Purger	39	Sensor Holder
17	Fuel Solenoid Valve	40	Fuel Tank
18	Air Regulator	41	Overflow Switch
19	Air Solenoid Valve	42	Overflow Tank
20	Air Distributor and Manometer	43	Photocell
21	Fuel Distributor (Double/Triple)	44	Tank Cover
22	Nozzle Adaptor	45	Air Safety Valve
23	Flame Ring (Double/Triple)		

4.5. Outer Dimensions

ECO WO-20/55



ECO WO-70/100/150/200



	L	Gmax	H	K	B	C	ØP	M	ØD
ECO WO-20/55	520	140	485	250	400	240	10	110	89
ECO WO-70/100/150/200	590	165	500	270	400	230	10	195	120

4.6. Noise Level

The product runs in min. 75 decibel max. 80 decibel range.

4.7. Basic Settings

When using synthetik oil, mix with min 10 % heating oil for start safety.

When using oil from plants, set oil temperature regulator to 80 - 100°C.

When using heating oil EL set oil temperature regulator to minimum.

Adjustment Thermostat	
Rape Seed Oil	60-140 °C
Multi Oil	60-100 °C
Heating EL/Diesel	0 °C (Not to heat)

4.8. Function Description

The combustible is pumped from the storage tank by **burner pump** into the burner tank.

A **floating switch** regulates the level in the burner tank.

An additional **micro switch** functions as a limit which indicates in case of overfilling.

A **contact switch** stops the burner in case of overflow in the tank.

A **thermostat** regulates the oil temperature in the burner tank and switches on the burner automatically as soon as the regulated temperature is reached.

An additional over heat thermostat prevents overheating with malfunctioning.

Then the **burner control** checks the procedure.


A special nozzle draws the fuel, by using the passing **compressed air**, which serves as primary air for the combustion, and atomizes it.

The **combustion fan** delivers the secondary air that is mixed with the spray mist at the **flame ring**.

The burner is equipped by a security valve. Opening pressure :

ECO WO-20 to ECO WO-100 - 1,2 bar, ECO WO-150 to ECO WO-200 - 1,5 bar

Thereby a perfect combustion and safe operating are guaranteed.





Warning

Burner has to be adjusted only by authorised qualified technicians according to the corresponding regulations.

5. REGULATIONS

Post regulation of oil consumption by the primary air regulator Post regulation of smoke number and CO₂ by secondary air regulator

5.1. Primary air regulator



Warning

Don't change the position of the pressure regulator after adjustment. Attention to proper locking of the turning knob !

5.2. Secondary air regulator

ECO WO-20
ECO WO-55
ECO WO-70

ECO WO-100
ECO WO-150
ECO WO-200



Optimum values:

smoke number as Bacharach “<1”

CO₂ = 10 to 11,5 Vol. %

Exhaust temperature according to the instruction manual of the heater/fire equipment Δt approx. 200°C

6. ATTENTION PLEASE - A SUMMARY OF IMPORTANT POINTS REGARDING ‘ECO WO’

1. Read operating instructions carefully, prior to installing and commissioning the heater.
2. The incorrect adjustment of the burner may destroy the combustion chamber and the heat exchanger; therefore, it is important that the output is correctly set. In order to avoid condensation, the net temperature of the flue gases (=the measured temperature of the flue gases in °C minus the inlet temperature of the burner in °C minus the inlet temperature of the burner in °C) must not drop below a value of 160°C (at space heaters).
3. The burner adjustment must be carried out by a specialist (after-sales service for the burner). The flames must on no account touch the walls of the combustion chamber.
4. Clean the combustion chamber and the heat exchanger **at least** once a year. Have the oil burner checked and serviced **at least** annually. Conclude a service contract.
5. Do not switch off at the master switch while heating .
6. Rectify the cause of defect before unlocking the overheat thermostat (warm air thermostat) or the overload relay.
7. In order to qualify for the guarantee, the device must be installed and commissioned by a specialist. The settings are to be recorded in a measurement certificate.
8. Please fill out all the points of the guarantee form correctly, sign, and send it to as ECO WO. Please note that in case of missing measuring values no guarantee certificate will be used.
9. In case of temperatures below 4°C, the oil should be heated in the reservoir (or in the unit tank respectively). (For the relevant heating cartridges, please refer to the accessories).
10. In order to protect the control of the heating please note the charging rate of the burner (if necessary, install an additional relais).

7. INSTALLATION & COMMISSIONING

- Ø ECO WO waste oil burners contain boiler connection flange and seal.
- Ø Connect the boiler connection flange and the seal to the boiler using 4 bolts.
- Ø Connect the burner to the boiler and tighten the bolts.
- Ø Install oil pipe from the storage tank.
- Ø Connect the connector coupling of a compressed air pipe with the connection nipple of the pressure reducer.



To avoid malfunctions we recommend the mounting of condensation drainage at the ducting between compressor and burner.

- Ø Connect the burner to a power source using the electrical diagram.

7.1. Setting Into Operation

1. When setting into operation for the first time, fill up the burner tank by hand to the oil level mark.



When the oil level is too high, the float switch switches off the burner automatically. If the oil level is too low, the cartridge heater will be damaged.



In case of overheating, the thermostat will switch off the burner. After cooling down, reengage thermostat:

- Unscrew protecting cap,
- Press reset button,
- Fix again the protecting cap.





2. Wait the burner will start automatically as soon as the fuel has reached the right operation temperature.

3. Post regulation of oil consumption by the primary air regulator and post regulation of smoke number and CO by secondary air regulator.



Don't change the position of the primary air pressure regulator after adjustment.


7.2. Flame Ring And Ignition Electrode



8. TROUBLESHOOTING

Problem	Cause	Explanation-Suggestion
Burner does not ignite or Flame interrupts and stops	Heating oil is not combustible due to sludge or water contamination	Open drain tap of burner tank, drain sludge and water or use better heating
	Oil tank empty	Refill with oil
	Oil level in burner tank too high	Correct oil level by draining through drain tap and readjust if necessary, float-switch-level setting
	Oil level in burner tank too low	Correct oil level and refill
	No ignition	Adjust ignition electrode and if replace necessary. Check transformer and ignition leads
	Photo cell dirty or not plugged in correctly	Clean photo cell, replace or plug it in correctly
	Burner control defective	Replace burner control
	No compressed air	Connect compressed air and adjust pressure
	Compressed air too low	Verify the compressed air (not below 2 bar)
Compressor or air pipe defective	Check compressor and air pipe and repair it	
No oil supply to the burner tank	Feeding pump dirty	Clean feeding pump strainer
	Strainer of the floating suction device is clogged	Clean strainer
	Motor capacitor defect	Replace motor capacitor
	Motor defect	Replace motor
Nozzle clogged or carbonized	Flame ring falsely set	Correct measuring of the flame ring
	Too much or too less compressed air	Correct gauge pressure
	To little ventilation in the heating room	Make ventilation openings big enough

9. ELECTRICAL DIAGRAM



11. AFTER SALES SERVICES

Dear Customer,

We believe that providing a good service is as important as providing a good product. Therefore, we continue offering wide range of comprehensive services to our conscious customers.

Our contact details for your requests and complaints

Esentepe Mah.Milangaz Cad. No:75 K:3

Kartal Monumento Plaza

KARTAL/İSTANBUL/TÜRKİYE

Tel: +90 216 442 93 00

Fax: +90 216 370 45 03

Factory Contact Details

Türkgücü OSB

Bülent Ecevit Bulvarı No:11

ÇORLU/TEKİRDAĞ/TÜRKİYE

Tel: +90 282 685 44 80-81

Fax: +90 282 685 42 09

Also you can contact with us:

Web site : www.ecostar.com.tr

E - mail : servis@ecostar.com.tr



Please observe the following recommendations.

- Use the product in accordance with the principles of this manual.
- For any service demands regarding the product, please contact our Service Center from the abovementioned phone numbers.
- Upon your purchase, register your warranty certificate during installation.

